

# ClearCourt Ball Tube™

## INSTRUCTIONS

Our **CLEARCOURT BALL TUBE™** (48" tall) makes ball pickup fun on any court! It can pick up pickleballs, tennis balls, and even red transition tennis balls. The flexible end caps are so soft that they won't crack or harm the court surface. A rubber band stopper holds balls inside when the tube is turned any direction. Each ClearCourt Ball Tube™ also includes an adjustable shoulder strap for even easier pickup and transport.



### TO PICK UP BALLS

Hold tube vertically over the ball.  
Press down firmly to retrieve the ball.  
Repeat until full.


### TO EMPTY TUBE

Remove the rubber band stopper and pour balls out.  
Use hook to hang on fence when not in use.



### BALL CAPACITY

17 pickleballs • 21 tennis balls  
18 red transition balls



### TO ADJUST STRAP

Pull shoulder strap to tighten. Lift buckle to loosen.

### NOTE

Please be careful to not overstretch the rubber band stopper as it may break. Also, when picking up regular tennis balls, you may need to give the tube a gentle "shake" to help with the pickup process.

Visit our site

